

# How to change U-boot configuration by BOOT.INI

---

In order to support easy boot loader setup, ODROID-C2 also support **boot.ini** as previous ODROID boards. So you can easily list up the commands what you want to executed in U-boot rather than the default. Here is the example to boot Ubuntu.

You can download the file below and copy into your FAT partition.

## Android boot.ini example

[boot.ini](#)

## Linux boot.ini example

[boot.ini](#)

## Board Identifier

This is the keyword to identify the correct **BOOT.INI** as per board. For **ODROID-C2**, any **BOOT.INI** must contain **ODROIDC2-UBOOT-CONFIG** and other commands must be below this.

## U-boot commands

You can describe multiple commands of U-boot from the next line of **ODROIDC2-UBOOT-CONFIG**. The commands are only restricted within the commands enabled by the running U-boot.

From:

<http://wiki.odroid.com/> - **ODROID Wiki**

Permanent link:

[http://wiki.odroid.com/odroid-c2/troubleshooting/change\\_u-boot\\_configuration](http://wiki.odroid.com/odroid-c2/troubleshooting/change_u-boot_configuration)

Last update: **2017/07/25 03:15**

