

Quick Setup

```
odroid : 2017-03-28 07:23:22
Ubuntu 16.04      Kernel 4.9.11
CPU Usage: 1.63%  CPU Temp: 52C
IP: 192.168.30.3  Rem: 106.250.177.234

/dev/sda1 Temp: 35
R/W 0.00 / 18.00 MB/s
Disk Used: 58M (1%) Free: 5.2T

/dev/sdb1 Temp: 35
R/W 0.00 / 18.00 MB/s
Disk Used: 58M (1%) Free: 5.2T
```

Introduction

This page introduce you how you can enable the LCD and Fan on/off service included with ODROID [cloudshell-2](#).

Installation

target

```
wget https://github.com/leeseungcheol/odroid-
cloudshell-2/raw/master/cloudshell-2-lcd_20170414-3_armhf.deb
sudo dpkg -i cloudshell-2-lcd_20170414-3_armhf.deb
sudo apt-get install -f
sudo reboot
```

From:
<https://wiki.odroid.com/> - ODROID Wiki

Permanent link:
https://wiki.odroid.com/accessory/add-on_boards/xu4_cloudshell2/quicksetup

Last update: 2019/04/26 17:46

