

ODROID-XU4 Boot Mode Configuration

ODROID-XU4 has a slide-switch to choose the boot media.

The boot configuration slide-switch must be set to boot from SD-card if you have no eMMC.

The device does NOT automatically fail-over (default) to SD-card if no eMMC is present.



From:
<http://wiki.odroid.com/> - **ODROID Wiki**

Permanent link:
http://wiki.odroid.com/odroid-xu4/hardware/bootmode_configuration

Last update: **2018/07/03 00:28**

